



PASSENGER PEG RELOCATION BRACKETS for Victory Octane Rally

(Installation of brackets)

Qty 4 – M8-1.25x20mm
Qty 2 – 5/16" -18x1 1/2"
Qty 2 – 5/16" -18x3/4"
Qty 2- 1/2" aluminum spacer
Left & Right Bracket

Start by removing muffler bolt from muffler bracket attached to muffler. Loosen bracket from bike enough to allow bracket to swing down out of the way.

Loosen rear and front head pipe bolts just enough to allow for pipe to rotate up and away from bike providing access to top & bottom bolt hole where original foot peg was attached. (START BELOW IF EXHAUST IS NOT ALREADY ON BIKE)

Right side bracket has a groove on bracket, make sure groove on bracket is facing inside of bike.

Slide supplied M8-1.25 x 20mm stainless bolt thru top bracket hole, align and fasten to top bolt hole, tightening top bolt.

Align bracket with lower bolt hole and insert supplied M8-1.25 x 20mm stainless bolt thru bracket hole and tighten

Securing right side OEM foot peg to bracket with spacers - Using supplied aluminum spacers, slide one spacer onto back of top hole of OEM foot peg. (Make sure spacer is placed between extension bracket and foot peg bracket). Align spacer with top hole and insert a 5/16" - 18x 1 1/2" button socket head bolt thru, securing foot peg to bracket. (Repeat process for lower hole in OEM foot peg)

Rotate front and rear exhaust pipes back down seating them into head ports and tighten front and rear head pipe bolts.

Reattach muffler bracket to the muffler tightening bolts

LEFT PASSENGER PEG:

Remove left side OEM passenger foot peg. You will need to use this.

With the arc of the passenger peg bracket facing toward front of bike, align bolt holes with the original holes on bike for left passenger foot peg. Slide M8-1.25 x 20mm bolts thru holes and tighten bolts securing bracket to bike. (Make sure the threaded holes are at the bottom of the bracket)

Using supplied 5/16" x 18-1 1/2" button head bolts, align top/bottom OEM foot peg holes with lower bracket threaded holes and insert bolts thru holes securing and tightening bolts.

Your passenger foot pegs should now be ready to use. Before usage be sure to check all nuts and bolts are fitted snug and secure.

