

SWING ARM BOLT COVER



Remove the nut and washer from your swing arm.

Looking into black bolt cover, make sure the short side of the inside platform of the cover is facing the outside of the bike.

Slide black bolt cover over bolt. Pushing bolt cover as far back as you can.

Slip on washer

Slide nut over bolt and fasten down snug with wrench.



SWING ARM BOLT COVER



Remove the nut and washer from your swing arm.

Looking into black bolt cover, make sure the short side of the inside platform of the cover is facing the outside of the bike.

Slide black bolt cover over bolt. Pushing bolt cover as far back as you can.

Slip on washer

Slide nut over bolt and fasten down snug with wrench.

